

Sony

A100	CABLE-S1
A200	CABLE-S1
A230	Ej kompatibel
A290	Ej kompatibel
A300	CABLE-S1
A3000	Ej kompatibel
A33	CABLE-S1
A330	Ej kompatibel
A35	CABLE-S1
A350	CABLE-S1
A37	CABLE-S1
A380	Ej kompatibel
A390	Ej kompatibel
A400	CABLE-S1
A450	CABLE-S1
A500	CABLE-S1
A55	CABLE-S1
A550	CABLE-S1
A550V	CABLE-S1
A560	CABLE-S1
A57	CABLE-S1
A58	Ej kompatibel

A580	CABLE-S1
A65	CABLE-S1
A65V	CABLE-S1
A700	CABLE-S1
A77	CABLE-S1
A77II	CABLE-S1
A77V	CABLE-S1
A850	CABLE-S1
A900	CABLE-S1
A99 II	CABLE-S2
A99	CABLE-S1
NEX-3	Ej kompatibel
NEX-3C	Ej kompatibel
NEX-5	Ej kompatibel
NEX-5C	Ej kompatibel
NEX-5N	Ej kompatibel
NEX-5T	Ej kompatibel
NEX-6	Ej kompatibel
NEX-7	Ej kompatibel
NEX-C3	Ej kompatibel
NEX-F3	Ej kompatibel
QX-10	Ej kompatibel

QX-100	Ej kompatibel
RX1	Ej kompatibel
RX1R	Ej kompatibel
A6000	CABLE-S2
A6300	CABLE-S2
A6500	CABLE-S2
A7-serien	CABLE-S2
A7 II-serien	CABLE-S2
A7 III-serien	CABLE-S2
HX300	CABLE-S2
HX50V	CABLE-S2
NEX 3N	CABLE-S2
RX10	CABLE-S2
RX10 II	CABLE-S2
RX100 II	CABLE-S2
RX100 III	CABLE-S2
RX100 IV	CABLE-S2
RX100 PLATINUM	CABLE-S2