

hähnel
quality accessories

www.hahnel.ie

CAPTUR Timer - KIT



Wireless Remote Shutter Release and Timer Remote

A Moment in Time

Time Lapse / Long Exposure



Module - Timer



Receiver

Available for major DSLR camera brands

Features & Benefits

For Canon:
Part No: 1000 715.0
EAN: 5099113007155

For Nikon:
Part No: 1000 716.0
EAN: 5099113007162

For Sony:
Part No: 1000 718.0
EAN: 5099113007186

For Oly/Pana:
Part No: 1000 717.0
EAN: 5099113007179

For Fuji:
Part No: 1000 719.0
EAN: 5099113007193

- Ideal for time-lapse photography
- Time Lapse & Bulb Exposures
- Single / Continuous / Bulb Modes
- Two Timing Sequences
- Connect to camera with connector cables supplied
- DCM - Digital Channel Matching
- AA Battery Powered
- 100m Range
- Additional receivers available to fire multiple DSLR's
- Can be integrated with other Captur Modules
- Larger easy to read LCD



Endless Possibilities

WIRELESS
UP TO
100m
2.4GHz



VIDEO DEMO



Previous Awards for Captur Range



QR Code Technology

A QR Code on each product pack, directs the user to LIVE, online and up to date compatibility information for each brand.



hähnel
quality accessories

DSLR Remote Controls


CAPTUR Timer - KIT



Wireless Remote Shutter Release and Timer Remote



Long Exposure - This type of photography can bring real life into your photographs by capturing moving objects with longer exposure times. Use the Module - Timer to create fantastic shots of starscapes, landscapes, seascapes & more.



Time Lapse Photography - Landscapes, clouds, slow growing plants & more come to life using time lapse photography. You can take multiple photographs at intervals over a long period of time & edit into a moving sequence. All of which is possible using the Module Timer.

Model	Part No.	Camera	Range	Wireless	Cable
Captur Timer - Kit Remote Control for Canon DSLR	1000 715.0	·1300D ·1200D ·1100D ·760D ·750D ·700D ·650D ·70D ·60D ·5D ·5D MK II ·5DMKIII ·5D MKIV ·5DS ·5DSR ·6D ·7D ·7D MKII ·1DS ·1DSMKII ·1DS MKIII ·G3X ·G5X ·G15 ·G16 ·SX60 ·1000D ·600D ·550D ·500D ·450D ·400D ·350D ·300D ·100D ·80D ·50D ·40D ·30D ·20DS ·20D ·10D ·1D ·1D MKII/II N ·III ·IV ·1DC ·1DX ·G1X ·G1X MKII ·G10 ·G11 ·G12 ·SX50 ·M5 Pentax: K-5 II/ K-5 Iis/ K-5/ K-7/ K-10/ K-20/ K-50/ K-100/ K-200/ K-500 Samsung: GX10/ GX20	Up to 100m	✓	✓
Captur Timer - Kit Remote Control for Nikon DSLR	1000 716.0	·D7200 ·D7100 ·D7000 ·D7500 ·D5500 ·D5300 ·D5200 ·D5100 ·D5000 ·D5600 ·D3300 ·D3200 ·D3100 ·D810 ·D800E ·D800 ·D750 ·D700 ·D610 ·D600 ·D500 ·D300 ·D300S ·D200 ·D90 ·D80 ·D70S ·D5 ·D4 ·D4S ·D3 ·D3S ·D3X ·D2H ·D2HS ·D2X ·D2XS ·D1 ·D1H ·D1X ·DF ·P7700 ·P7800 ·COOLPIX A	Up to 100m	✓	✓
Captur Timer - Kit Remote Control for Sony DSLR	1000 718.0	·RX100 ·RX10 ·RX10 II ·Mk2 ·Mk3 ·Mk4 ·A58K ·A58Y ·NEX-3N ·A7 ·A7II ·A7R ·A7R II ·A7s ·A7s MkII ·A3000 ·A6000 ·A6300 ·A6500 ·A33 ·A3 ·A35 ·A37 ·A55 ·A57 ·A65 ·A68 ·A77 ·A77 MkII ·A100 ·A200 ·A300 ·A350 ·A450 ·A500 ·A550 ·A560 ·A580 ·A700 ·A850 ·A900 ·A99 ·A5000 ·HX50 ·HX50V ·HX60 ·HX60V ·HX300 ·HX400 ·HX400V	Up to 100m	✓	✓
Captur Timer - Kit Remote Control for Fuji DSLR	1000 719.0	·X-A1 ·A2 ·E2 ·M1 ·Q1 ·Q2 ·T1 ·T10 X30 ·X100T ·X-T20 ·Finepix S1 ·X-S1 ·E1 ·HS20EXR ·Z2EXR ·Z5EXR ·Z8EXR ·Z30EXR ·Z33EXR ·Z35EXR ·S100FS ·S200EXR ·S205EXR ·X-T2 ·X70 ·X-PRO 2 ·X-A3 ·GFXS0 S	Up to 100m	✓	✓
Captur Timer - Kit Remote Control for Olympus / Panasonic DSLR	1000 717.0	Olympus: ·OM-DE-M1 ·M1 II ·M5 ·M5 II ·M10 ·M10 II ·PEN-F ·PL7 ·PL6 ·PM2 ·SP-100 ·STYLUS 1 ·STYLUS 1S ·XZ-2 ·S90UZ ·E5 ·PEN E-PL8 Panasonic: ·GX8 ·GX7 ·G1 ·G70 ·G10 ·G7 ·G6 ·G5 ·G80 ·G85 ·FZ300 ·FZ330 ·FZ2000 ·FZ2500	Up to 100m	✓	✓

